

X-uDMX512 for Macintosh
DMX USB Interface

Thank you for using the X-uDMX512, a micro processor enabled DMX USB interface.

You can find all the X-uDMX512 for Macintosh files in the CD-ROM. Besides, you can download it through our website:

<http://www.xzlgroupp.com/products2/mac/X-uDMX512-for-Macintosh.rar>

(1) Installer packages for Macintosh

The X-uDMX512 needs [libusb 0.1](#) in order to function (libusb 1.0 will not work). For Macintosh, you can find installer packages here:

- MacOS Leopard/Snow Leopard (10.5, 10.6) www.ellert.se/PKGS/

Or, you can download it directly here:

<http://www.xzlgroupp.com/products2/mac/libusb.rar>

- MacOS Lion/Mountain Lion: www.ellert.se/PKGS/libusb-2012-10-21/

(2) External for Max/MSP and PureData

You can download external for Max/MSP and PureData through below links:

- (1) X-uDMX512 external for Max/MSP (macintosh) version 2010-06-07.
<http://www.xzlgroupp.com/products2/mac/udmx-MAXMSP-mac-100607.zip>
- (2) X-uDMX512 external for Max/MSP (macintosh) version 2009-08-17. Includes outlets for connection status and messages. For Max 4.6 and Max5
<http://www.xzlgroupp.com/products2/mac/udmx-MAXMSP-mac-090817.zip>
- (3) X-uDMX512 external for Puredata (macintosh) 32bit version.
http://www.xzlgroupp.com/products2/mac/uDMX_pd_intel_32bit.zip
- (4) X-uDMX512 external for Puredata (macintosh) 64bit version.

http://www.xzlgroupp.com/products2/mac/uDMX_pd_intel_64bit.zip